



JUMP STARTING  
**POWER PACK**


**70**

**QUICK START GUIDE**

Model N70



# GETTING TO KNOW WEEGO 70




## CHARGE UP YOUR WEEGO 70

When you unpack your new Weego 70 for the first time, charge it up to 100% with either the wall or car charger and included USB-C charging cord. Remember to recharge your Weego 70 every 6 months, even when you're not using it – it will help extend its lifespan.

## POWERING ON/OFF

There's a **Power ON/OFF Button** on the back of your Weego 70. While powered "ON", the blue power button will remain illuminated. *Make sure you turn OFF your Weego 70 after every use; leaving it on slowly drains the battery.*



*It takes 3.5 hrs. to fully charge. The indicator lights will flash one by one while the unit is charging. A solid light indicates a completed level of charge.*

# JUMP STARTING

## BEFORE YOU JUMP

- ➔ Read all instructions and safety information prior to using this product. Improper use of this product will void your warranty and may result in product damage, excess heat, toxic fumes, fire, and other unsafe conditions for which Weego is not responsible.
- ➔ Read vehicle owner's manual first: it may have specific cautions and instructions about jumping your engine.
- ➔ This product is for use on **12V Lead-Acid** batteries only! **DO NOT** use this product on any other voltage battery, such as 6V, 24V, etc. **DO NOT** use this product on lithium-ion batteries.
- ➔ Never jump an engine in an enclosed area.
- ➔ Put your vehicle in **PARK** and engage the emergency brake (boats and powersports' vehicles should be put in **NEUTRAL**).
- ➔ **TURN OFF ALL ELECTRONICS!** – air conditioner, radio, lights, etc.
- ➔ Remove any devices attached to your Weego 70.
- ➔ Never leave your Weego 70 connected to your engine's battery unless actively jumping.
- ➔ Always disconnect the **Smarty Clamps®** from your Weego 70 when not in use.

**WEEGO CUSTOMER SUPPORT** We are dedicated to providing the best possible service. To reach Weego Customer Support, visit [myweego.com/support](https://myweego.com/support) or email [support@myweego.com](mailto:support@myweego.com).



**Connect Clamps**



**Power ON**



**Attach Black (-), Then Red (+)**



**When You Have SOLID GREEN LIGHT On Your Smart Box, Start Your Engine**



**Once it Starts, Disconnect Clamps from Weego 70**



**Detach Clamps From Battery**

# JUMP STARTING YOUR ENGINE

1. Ensure your engine is completely OFF.
2. Securely connect the **Smarty Clamps**® to your Weego 70, then power ON.
3. Attach **BLACK** clamp to your battery's negative (-) terminal, then the **RED** clamp to your battery's positive (+) terminal. Adjust your **Smarty Clamps**® to achieve MAXIMUM contact with the terminals. Poor connections will prevent you from starting your engine! *Clear off any dirt or build-up with a wire brush or a dry towel before connecting your clamps.*
4. Place your Weego 70 in a secure location or suspend using the provided hook & lanyard so it won't fall. Check your **Smarty Clamps**® lights.
5. When you have a **SOLID GREEN READY** light, start your engine. *If the engine doesn't start, turn off your vehicle and check your **Smarty Clamps**® lights.*
6. After a successful start, quickly disconnect the **Smarty Clamps**® from your Weego 70.
7. Detach the **Smarty Clamps**® from the battery.
8. You're now good to go - be sure to run your engine for at least 15 minutes before shutting it off again so it has time to recharge your battery.

If you are having issues getting your engine started, see the **Troubleshooting** section in your quick start guide, owners manual or on [myweego.com](https://myweego.com) for further details and assistance.

## WARNING!

Exposed Metal Jaws May Be HOT After Use!

# UNDERSTANDING YOUR *Smarty Clamps*®

Your *Smarty Clamps*® have a “smart” box that will help guide you through a jump with both sight and sound. It will let you know when it is safe to jump or if there is an error.



● **READY**

**Solid Green Light, No Sound**

*Smarty Clamps*® detect that you have a good connection and you are ready to jump.

● **REVERSE +/-**

**Solid Red Light + Solid Beep**

You attached the *Smarty Clamps*® on the wrong terminals. Make sure the **BLACK** clamp is attached to the battery's **NEGATIVE (-)** terminal, and the **RED** clamp is attached to the battery's **POSITIVE (+)** terminal. If not attached properly, Weego 70 will not let you jump your engine.



**COOL DOWN  
WAIT FOR**

**Flashing Red/Green Light**

The Weego battery overheats after long cranks or excessive current draw. Detach the *Smarty Clamps*® from the battery and give the unit up to 3 minutes to cool down. Then, repeat steps 2-5 under *Jump Starting Your Engine*.



○ **SEE REVERSE** **No Light/Flashing Green Light**

Either you have a poor connection, or your battery voltage is near 0 volts. Press the **BYPASS\*** button, when **SOLID GREEN** light is on, start engine.

**Note:** If you cannot complete the jump the system voltage of your vehicle may not be compatible with your Weego 70 (for 12V vehicles only).

*\*Using BYPASS feature will override safety features.*



**Bypass Button**

# TROUBLESHOOTING

Visit [www.myweego.com/support](http://www.myweego.com/support) for FAQs and additional troubleshooting inquiries and details.

## **My unit won't power on/charge/charge past a few lights**

*If your unit won't power on, won't take a charge OR won't charge past a few lights then it's been overdischarged. This can happen if the unit is left ON, or if an engine pulled the Weego battery past a certain limit during a jump start.*

*Please reach out to [support@myweego.com](mailto:support@myweego.com) to let them know about this issue – we'll receive and test the overdischarged Weego, then determine if we can repair it or if it needs to be fully replaced.*

## **The Weego won't jump start my vehicle**

*We have listed below a few things that can cause a failed jump start:*

- **Poor connection between the Weego clamps and vehicle battery:** *the better the connection, the more likely you are to have a successful jump*
- **Dirty battery terminals:** *build up prevents all the available power from reaching your battery*
- **Vehicle-specific compatibility issues:** *occasionally we come across a vehicle that has unique power demands that a smaller model cannot fulfill, even though it's within our recommended engine range. In addition, vehicles with heavier electronics can sometimes create issues when jumping with a Weego; we mostly see this in push-to-start vehicles.*
- **Cold temperatures:** *Freezing temperatures create a lot of resistance in an engine which means it can require up to 3.5X the usual amount of power to get started; for example, an engine that usually needs 200A could need up to 700A in the extreme cold. In addition, if your Weego was stored in the cold temps it will make it harder for the Weego to deliver its full power.*
- **Low-Charged Weego:** *it's always best to work with full power on your Weego if you can. Our jump starters perform better at 100% charge than they do at 20% charge, especially when jumping larger engines.*

# USB-A & USB-C CHARGING

Charge your phone, tablet and other portable devices with your Weego 70. Weego 70 comes equipped with **Detect-o-Matic™** USB Fast Charging.

You can charge your USB-A devices by plugging in your own USB-A cord into your Weego 70 USB-A port OR by plugging the your own USB-C to USB-C cord into your Weego 70 USB-C input/output port. Connect to your device, power on Weego 70 and start charging!



USB-A  
Output Port

USB-C  
Input/Output Port



## LIGHTING

Your Weego 70 comes with a 600 lumen LED flashlight. Power on your Weego 70, then briefly press and release the flashlight button to initiate the following sequences:

- 1<sup>st</sup> click: Normal
- 2<sup>nd</sup> click: Strobe
- 3<sup>rd</sup> click: SOS
- 4<sup>th</sup> click: OFF

Your Weego 70 will give you **up to 15 hours of flashlight time** and **up to 30 hours of strobe & SOS light** on a full charge.



Flashlight Button