




120

## Model C120



# GETTING TO KNOW WEEGO 120




## CHARGE UP YOUR WEEGO 120

When you unpack your new Weego 120 for the first time, charge it up to 100% with either the wall or car charger and included USB Type-C charging cord. Remember to recharge your Weego 120 every 6 months, even when you're not using it – it will help extend its lifespan.

## POWERING ON/OFF

There's a **Power Button** on your Weego 120. While powered "ON", the blue indicator lights will remain illuminated. *Your Weego 120 will automatically turn off after 10 seconds if you do not use it. This conserves battery power.*



### Indicator Lights Sequence:

*It takes 6 hrs. to fully charge. The indicator lights will flash one by one while the unit is charging. A solid light indicates a completed level of charge.*

# JUMP STARTING

## BEFORE YOU JUMP

- ➔ Read all instructions and safety information prior to using this product. Improper use of this product will void your warranty and may result in product damage, excess heat, toxic fumes, fire, and other unsafe conditions for which Weego is not responsible.
- ➔ Read vehicle owner's manual first: it may have specific cautions and instructions about jumping your engine.
- ➔ This product is for use on **12V Lead-Acid** batteries only! **DO NOT** use this product on any other voltage battery, such as 6V, 24V, etc. **DO NOT** use this product on lithium-ion batteries.
- ➔ Never jump an engine in an enclosed area.
- ➔ Put your vehicle in **PARK** and engage the emergency brake (boats and powersports' vehicles should be put in **NEUTRAL**).
- ➔ **TURN OFF ALL ELECTRONICS!** – air conditioner, radio, lights, etc.
- ➔ Remove any devices attached to your Weego 120.
- ➔ Never leave your Weego 120 connected to your engine's battery unless actively jumping.
- ➔ Always disconnect the clamps from your Weego 120 when not in use.

**WEEGO CUSTOMER SUPPORT** We are dedicated to providing the best possible service. To reach Weego Customer Support, visit [myweego.com/support](https://myweego.com/support) or email [support@myweego.com](mailto:support@myweego.com).



**Attach Black (-), Then Red (+)**



**When You Have **SOLID GREEN LIGHT** On Your Unit, Start Your Engine**



**Once it Starts, Detach Clamps from Battery**

# JUMP STARTING YOUR ENGINE

1. Ensure your engine is completely OFF.
2. Securely connect the clamps to your Weego 120, then attach **BLACK** clamp to your battery's negative (-) terminal, then the **RED** clamp to your battery's positive (+) terminal. Adjust your clamps to achieve MAXIMUM contact with the terminals. Poor connections will prevent you from starting your engine! *Clear off any dirt or build-up with a wire brush or a dry towel before connecting your clamps.*
3. Place your Weego 120 in a secure location so it won't fall. Check your indicator signals.
4. When you have a **SOLID GREEN READY** light, start your engine. *If the engine doesn't start, turn off your vehicle and check your indicator signals.*
5. After a successful start, quickly disconnect the clamps from your vehicle battery.
6. You're now good to go - be sure to run your engine for at least 15 minutes before shutting it off again so it has time to recharge your battery.

If you are having issues getting your engine started, see the **Troubleshooting** section in your quick start guide, owners manual or on [myweego.com](http://myweego.com) for further details and assistance.

## WARNING!

Exposed Metal Jaws May Be HOT After Use!

## UNDERSTANDING INDICATOR SIGNALS

Your unit has “smart” indicator signals that will help guide you through a jump with both sight and sound. It will let you know when it is safe to jump or if there is an error.



### ● READY      **Solid Green Light, No Sound**

The clamps detect that you have a good connection and you are ready to jump.



### ● REVERSE +/-      **Solid Red Light + Solid Beep**

You attached the clamps on the wrong terminals. Make sure the **BLACK** clamp is attached to the battery's **NEGATIVE (-)** terminal, and the **RED** clamp is attached to the battery's **POSITIVE (+)** terminal. If not attached properly, Weego 120 will not let you jump your engine.



### ☀ COOL DOWN      **Flashing Red Light** WAIT FOR ●

The Weego battery overheats after long cranks or excessive current draw. Detach the clamps from the battery and give the unit up to 3 minutes to cool down. Then, repeat steps 2-4 under *Jump Starting Your Engine*.

### ○ No Light

Either you have a poor connection, or your battery voltage is near 0 volts. Press the **BYPASS\*** button, when **SOLID GREEN** light is on, start engine.

**Note:** If you cannot complete the jump the system voltage of your vehicle may not be compatible with your Weego 120 (for 12V vehicles only).

*\*Using BYPASS feature will override safety features.*

**Bypass Button**

# TROUBLESHOOTING

Visit [www.myweego.com/support](http://www.myweego.com/support) for FAQs and additional troubleshooting inquiries and details.

## **My unit won't power on/charge/charge past a few lights**

*If your unit won't power on, won't take a charge OR won't charge past a few lights then it's been overdischarged. This can happen if the engine pulled the Weego battery past a certain limit during a jump start. It can also happen if the Weego is not stored with a full charge, or is not recharged every 6 months during storage.*

*Please reach out to [support@myweego.com](mailto:support@myweego.com) to let them know about this issue – we'll receive and test the overdischarged Weego, then determine if we can repair it or if it needs to be fully replaced.*

## **The Weego won't jump start my vehicle**

*A few things can attribute to a failed jump start, which we listed below.*

- **Poor connection between the Weego clamps and vehicle battery:** *the better the connection, the more likely you are to have a successful jump.*
- **Dirty battery terminals:** *build up prevents all the available power from reaching your battery.*
- **Vehicle-specific compatibility issues:** *occasionally we come across a vehicle that has unique power demands that a smaller model cannot fulfill, even though it's within our recommended engine range. In addition, vehicles with heavier electronics can sometimes create issues when jumping with a Weego; we mostly see this in push-to-start vehicles.*
- **Cold temperatures:** *Freezing temperatures create a lot of resistance in an engine which means it can require up to 3.5X the usual amount of power to get started; for example, an engine that usually needs 200A could need up to 700A in the extreme cold. In addition, if your Weego was stored in the cold temps it will make it harder for the Weego to deliver its full power.*
- **Low-Charged Weego:** *it's always best to work with full power on your Weego if you can. Our jump starters perform better at 100% charge than they do at 20% charge, especially when jumping larger engines.*

# USB CHARGING

Charge your phone, tablet and other portable devices with your Weego 120 using your own USB charging cord. Your Weego 120 comes equipped with **Detect-o-Matic™** USB Charging. This intelligent charger communicates with your device to detect and deliver the fastest-possible charge.

To charge your devices, plug your charging cord into your Weego 120 USB port and connect to your device. Power on your Weego 120 and start charging!



# LIGHTING

Your Weego 120 comes with a 500 lumen LED flashlight. Power on your Weego 120, then briefly press and release the flashlight button to initiate the following sequences:

- 1<sup>st</sup> click: Normal
- 2<sup>nd</sup> click: Strobe
- 3<sup>rd</sup> click: SOS
- 4<sup>th</sup> click: OFF

Your Weego 120 will give you **up to 15 hours of flashlight time** and **up to 30 hours of strobe & SOS light** on a full charge.

